FIG. 1





FIG. 2








FIG. 4




FIG. 5




FIG. 6




FIG. 7




FIG. 8




FIG. 9




FIG. 10




FIG. 11




FIG. 12






FIG. 13



Steering Angles $\alpha 1$ Through $\alpha 4$ When $\alpha _{o}$ is Used as the Steering Command Value (Steering Mode M1)

FIG. 14



Steering Angles $\alpha 1$ and $\alpha 2$ When α_0 is Used as the Steering Command Value (Steering Mode M3)